



1. Fasten ring screws until scope can just barely be rotated freely in rings.
2. Snug LevelDrive screw against the flat base of scope.
3. Rotate scope in rings while re-snugging LevelDrive screw.
4. Repeat as necessary until scope can no longer be rotated, and no gap is visible between screw and base.
5. Progressively tighten ring screws in an alternating pattern to max torque.
6. Remove LevelDrive screw from mount prior to shooting.

MAX TORQUE 25 INCH-LBS

7. Open clamp by turning each ClickDrive wheel counter clockwise, a few clicks at a time, in an alternating pattern (Do not open further than internal stops allow).
8. Hook Leap mount onto rail from ClickDrive side.
9. Turn each ClickDrive wheel clockwise, a few clicks at a time, in an alternating pattern, until they are as tight as you can make them by hand (Do not use tools).

