



**1.** Attach optic onto Low Drag Mount by tightening supplied Nylok® Torq-Patch® treated screws, in an alternating pattern, to 37in-lbs, using a 3mm hex socket driver.

**2.** Unload and make weapon safe **3.** Turn thumbscrew counter-clockwise to open clamp **4.** Hook and pivot Low Drag Mount onto rail until fully seated **5.** Turn thumbscrew clockwise to close clamp onto rail, until thumbscrew is hand-tight.